Cheri Sawyer

WTCI-27-P

From: Shyam Sunder [sunder@nist.gov]
Sent: Thursday, November 14, 2002 5:27 PM
To: ddevans@nist.gov; rbukowski@nist.gov; jason.averill@nist.gov; rgann@nist.gov; james.lawson@nist.gov
Cc: hsl@nist.gov; jgross@nist.gov; terri@nist.gov; fahim.sadek@nist.gov; cauffman@nist.gov; johnsonc@nist.gov; cheri.sawyer@nist.gov
Subject: Fwd: WTC Documents

elevatorsu elevatorsu
ıry1.xls (16ry2.xls (16

FYI (please log). Shyam

==========

Provided by PANYNJ

>X-Sieve: CMU Sieve 2.2
>From: "Bhol, Saroj" <sbhol@panynj.gov>
>To: "Shyam Sunder (E-mail)" <sunder@nist.gov>
>Cc: "Fadavi, Ali" <afadavi@panynj.gov>, "Lin, C. John" <jlin@panynj.gov>,
> "Seliga, Nancy" <nseliga@panynj.gov>
>Subject: WTC Documents
>Date: Thu, 14 Nov 2002 13:42:00 -0500
>X-Mailer: Internet Mail Service (5.5.2653.19)
>
>Shyam,
>
>Here's the elevator numbering system for the WTC elevators, you
>requested:
>
> <<elevatorsummary1.xls>> <<elevatorsummary2.xls>>
>
>Thanks
>
>Saroj
>

==========
Dr. S. Shyam Sunder
Chief, Materials and Construction Research Division
Building and Fire Research Laboratory
National Institute of Standards and Technology
100 Bureau Drive Stop 8610 (Building 226, Room B 256) Gaithersburg, MD 20899-8610
Tel.: 301-975-6061/6713
Fax: 301-975-6122
==========

WORLD TRADE CENTER ELEVATORS				
ONE AND TWO WORLD TRADE CENTER				
	TYPE OF ELEVATOR	NUMBER	FLOORS SERVED	COMMENT
ONE WTC	Passenger Shuttle	1-4, 8-11	Lobby to 44th Floor Skylobby	
		12-16, 18-23	Lobby to 78th Floor Skylobby	Elevators 16, 18 and 19 used as Interzone
				between Skylobbies 44 & 78
		6 & 7	B1 to Lobby express to 106/107	6 also used as freight when possible
				7 could stop on 67 if keyed
	Passenger Locals	24-29	Lobby express to 9 up to 16	Crossover on 11 for Bank America
		30-35	Lobby express from 17 up to 24	Crossover on 24 for Empire
		36-41	Lobby express to 25 up to 32	
		42-47	Lobby express to 33 up to 40	
		51-56	Skylobby to 45 up to 53	
		57-62	Skylobby express to 54 up to 61	
		63-68	Skylobby express to 61 up to 67	66 and 67 also went down to 43
		69-74	Skylobby express to 67 up to 74	
		75-80	Skylobby to 79 up to 86	78 and 79 also went down to 77 and up to 79
		81-86	Skylobby express to 87 up to 93	
		87-92	Skylobby express to 94 up to 100	
		93-98	Skylobby express to 101 up to 106	
	Passenger	FE9	43 and 44 only	PA Cafeteria car
	Passenger	J1, J2 and J3	Lobby to B6	Had to be keyed to go below B4
	Passenger	99	106 to 110	
	Freight	5	B1 to 40th floor	
		48	B1 to 44th Floor	
		17	B1 to 78th Floor	
		49	B1 to 44 to 74th Floor	
		50	B4 to 108th Floor	
		FE5	B1 to B3	
		FE8	B1 to Mall	Armored car
		J4	B1 to Mall	

WORLD TRADE CENTER ELEVATORS				
ONE AND TWO WORLD TRADE CENTER				
	TYPE OF ELEVATOR	**NUMBER**	**FLOORS SERVED**	**COMMENT**
TWO WTC	Passenger Shuttle	1-4, 8-11	Lobby to 44th Floor Skylobby	
		12-16, 18-22	Lobby to 78th Floor Skylobby	Elevators 16, 18 & 19 used as Interzone
				between Skylobbies 44 & 78
		6 & 7	B1 to Lobby express to 106/107	6 also used as freight car if possible
	Passenger Locals	24-29	Lobby express to 9 up to 16	
		30-35	Lobby express to 17 up to 24	
		36-41	Lobby express to 25 up to 30	
		42-47	Lobby express to 31 up to 40	
		51-56	Skylobby express to 45 up to 53	
		57-62	Skylobby express to 54 up to 61	
		63-68	Skylobby express to 61 up to 67	66 and 67 also went down to 43
		69-74	Skylobby express to 67 up to 74	72 stopped on 61
		75-80	Skylobby to 79 up to 86	78 and 79 went down to 77 and up to 79
		81-86	Skylobby express to 87 up to 93	
		87-92	Skylobby express to 94 up to 99	87, 88, 90 & 91 stopped on 90
		93-98	Skylobby express to 100 up to 106	
	Passenger	K3, K4 and K5	Lobby to B6	Had to be keyed to go below B4
	Passenger	99	106 to 110	Access by key only
	Freight	5	B1 to 40th floor	
		48	B1 to 44th Floor	
		17	B1 to 78th Floor	
		49	B1 to 44 to 74th Floor	
		50	B4 to 108th Floor	
		FE6	B1 to B4	
		K1	B1 to B6 operated by key only	
		K2	B1 to B6 operated by key only	
		P1	Lobby to B4	